



Chassis Quick Reference


Major Components






Installing Hard Drive




Remove Drive Tray




Rear Windows Configuration




Installing PCI Riser Card



Installing Slim CD-ROM & Slim FDD



TOP COVER CAUTION




CAUTION

This unit must be operated with the chassis TOP COVER installed to ensure proper cooling

Front Panel Controls and Indicators

- A. System reset button
- B. Buzzer reset button
- C. Power switch
- D. Power LED
- E. HDD LED
- F. LAN1 LED
- G. LAN2 LED
- H. Fan fail LED



Installing Backplane Assembly

