

Table of Contents

Ordering Policies and Guidelines	1-1
Server Consolidation Trade-In Program.....	1-5
Enterprise Appliances	2-1
Sun Ray 1 Enterprise Appliance Configuration	2-3
Sun Ray 1 Enterprise Appliance.....	2-4
Sun Ray Enterprise Server Software 1.1	2-5
Workstations	3-1
UltraSPARC Workstations Product Line Overview	3-2
Sun Ultra 5 System Configurations.....	3-6
Sun Ultra 5 Systems	3-8
Sun Ultra 5 Options	3-12
Sun Ultra 10 System Configurations.....	3-14
Sun Ultra 10 Systems	3-16
Sun Ultra 10 Options	3-23
Sun Ultra 60 System Configurations.....	3-25
Sun Ultra 60 Systems	3-26
Sun Ultra 60 Options	3-28
Sun Ultra 80 System Configurations.....	3-30
Sun Ultra 80 Systems	3-32
Sun Ultra 80 Options	3-34
Sun Configure-to-Order (CTO) Ordering Flow Chart	3-36
Sun CTO Options	3-38
Network and Telco Servers	4-1
Sun Netra t 1120/ Netra t 1125 ATO Ordering Flow Chart	4-2
Sun Netra t 1120 Fixed Config Ordering Flow Chart	4-4
Sun Netra t 1125 Ordering Flow Chart	4-6
Sun Netra t 1120/ Netra t 1125 Configuration Guidelines	4-8
Sun Netra t 1120 Telco Servers.....	4-11
Sun Netra t 1125 Telco Servers.....	4-12
Sun Netra t 1120/Netra t 1125 Options	4-13
Sun Netra t 1400/ Netra t 1405 ATO Ordering Flow Chart	4-15
Sun Netra t 1400 Fixed Config Ordering Flow Chart	4-17
Sun Netra t 1405 Fixed Config Ordering Flow Chart	4-19
Sun Netra t 1400/ Netra t 1405 Configuration Guidelines	4-21
Sun Netra t 1400 Telco Server	4-23
Sun Netra t 1405 Telco Server	4-24
Sun Netra t 1400/Netra t 1405 Options	4-25
Sun Netra t1 Ordering Flow Chart	4-27
Sun Netra t1 Configuration Guidelines	4-28

Table of Contents

Sun Netra t1 Model 105 Network Servers.....	4-29
Sun Netra t1 Model 100 Network Servers.....	4-30
Sun Netra t1 Model 105/100 Network Servers Options.....	4-31
Sun Netra st D130.....	4-32
Sun Netra st A1000/D1000 Ordering Flow Chart.....	4-33
Sun Netra st A1000/D1000 Storage Arrays	4-34
Sun Netra ft 1800 Ordering Flow Chart	4-36
Sun Netra ft 1800 Configuration Guidelines.....	4-39
Sun Netra ft 1800 Telco Server	4-41
SPARC Workgroup Servers	4-43
SPARC Workgroup Servers Product Line Overview.....	4-44
Sun Enterprise Ultra 5S Systems.....	4-46
Sun Enterprise Ultra 5S Options	4-47
Sun Enterprise Ultra 10S Systems.....	4-48
Sun Enterprise Ultra 10S Options	4-49
Sun Enterprise 250 Ordering Flow Chart.....	4-50
Sun Enterprise 250 Sample Configurations.....	4-53
Sun Enterprise 250 Configuration Overview	4-54
Sun Enterprise 250.....	4-55
Sun Enterprise 250 Options.....	4-57
Sun Enterprise 450 Ordering Flow Chart.....	4-60
Sun Enterprise 450 Sample Configurations.....	4-63
Sun Enterprise 450 Configuration Overview	4-64
Sun Enterprise 450.....	4-65
Sun Enterprise 450 Options.....	4-67
Sun Enterprise 220R Ordering Flow Chart	4-70
Sun Enterprise 220R Sample Configurations.....	4-73
Sun Enterprise 220R.....	4-74
Sun Enterprise 220R Options	4-75
Sun Enterprise 420R Ordering Flow Chart	4-77
Sun Enterprise 420R Sample Configurations.....	4-80
Sun Enterprise 420R.....	4-81
Sun Enterprise 420R Options	4-82
Mid-Range/Data Center Servers	4-84
Sun Enterprise Overview.....	4-85
Sun Enterprise Overview.....	4-86
Enterprise 3500 - 6500 Ordering Flow Chart for Factory-Configured System Building Blocks.....	4-87
Enterprise 3500 - 6500 System Configuration Guidelines.....	4-91
Enterprise 3500-6500 CTO CPU/Memory Board Flowchart.....	4-99

Table of Contents

Enterprise 3500-6500 Configure-to-Order CPU/Memory Boards	4-100
Enterprise 3500 and 4500 Sample Configurations	4-101
Enterprise 5500 and 6500 Sample Configurations	4-103
Enterprise 3500 - 6500 Configuration Overview	4-104
Enterprise 3500 - 6500	4-109
Enterprise 3500 - 6500 Options.....	4-115
Enterprise 3500 and 4500 Ordering Flow Chart	4-120
Enterprise 5500 and 6500 Ordering Flow Chart	4-123
Enterprise 3500 - 6500 Capacity-On-Demand Building Block Guidelines	4-125
Enterprise 3500 - 6500 Capacity-On-Demand Requirements.....	4-126
Enterprise 3500-6500 Capacity-On-Demand Ordering Flow Chart.....	4-127
Enterprise 3500 - 6500 Capacity-On-Demand	4-129
High-End/Data Center Servers	4-130
Sun Enterprise Overview.....	4-131
Enterprise 10000 Ordering Flow Chart	4-132
Enterprise 10000 Power Express Ordering Flow Chart	4-136
Enterprise 10000 System Configuration Guidelines	4-138
Enterprise 10000 Sample Configurations.....	4-141
Enterprise 10000 Configuration Overview.....	4-142
Enterprise 10000.....	4-144
Enterprise 10000 Options	4-149
Enterprise 10000 Configure to Order Flow Chart.....	4-150
Enterprise 10000 Configure to Order Guidelines.....	4-151
Enterprise 10000 Configure to Order Options	4-152
Enterprise 10000 Capacity-On-Demand Ordering Flow Chart.....	4-153
Enterprise 10000 Capacity-On-Demand System Configuration Guidelines.....	4-156
Enterprise 10000 Capacity-On-Demand Sample Configurations	4-157
Enterprise 10000 Capacity-On-Demand Information	4-158
Enterprise 10000 Capacity-On-Demand CTO Flow Chart	4-159
Enterprise 10000 Capacity-On-Demand CTO Guidelines	4-160
Enterprise 10000 Configure to Order CTO Options	4-161
Enterprise 10000 non-Capacity-On-Demand TO COD Conversion Flow Chart.....	4-162
Enterprise 10000 non-Capacity-On-Demand TO COD Conversion Guidelines.....	4-163
Disk Arrays and Expansion Cabinet Disk Options	5-1
StorEdge A1000	5-3
StorEdge A1000 Compatibility Matrix	5-4
StorEdge D1000	5-7
StorEdge D1000 Compatibility Matrix	5-8
StorEdge A1000/D1000 Options.....	5-11

Table of Contents

StorEdge A1000/D1000 Options Compatibility Matrix.....	5-12
StorEdge A3500/A3500FC Ordering Flow Chart.....	5-15
StorEdge A3500-Light Ordering Flow Chart.....	5-17
StorEdge A3500/A3500FC Configuration Guidelines.....	5-18
StorEdge A3500-Light Configuration Guidelines.....	5-20
StorEdge A3500/A3500FC Configuration Overview	5-21
StorEdge A3500 Support Matrix.....	5-23
StorEdge A3500FC Support Matrix.....	5-23
StorEdge A3500/A3500FC	5-24
StorEdge A3500/A3500FC Compatibility Matrix	5-25
StorEdge A3500/A3500 Light.....	5-26
StorEdge A3500/A3500 Light Compatibility Matrix.....	5-27
StorEdge A3500FC	5-28
StorEdge A3500/A3500FC Options.....	5-30
StorEdge A3500/A3500FC Options Compatibility Matrix.....	5-31
StorEdge A3500 Light Options	5-34
StorEdge A5X00 Ordering Flow Chart - Stand Alone Models.....	5-36
StorEdge A5X00 Ordering Flow Chart - Factory Configured Cabs	5-37
StorEdge A5X00 Configuration Guidelines.....	5-38
StorEdge A5X00 Sample Configurations.....	5-40
StorEdge A5100 Configuration Overview	5-41
StorEdge A5X00 Support Matrix.....	5-43
StorEdge A5100 - 36GB Model	5-44
StorEdge A5100 - 36GB Model Compatibility Matrix.....	5-45
StorEdge A5200 Configuration Overview - 9GB Model.....	5-48
StorEdge A5200 - 9GB Model	5-49
StorEdge A5200 - 9GB Model Compatibility Matrix.....	5-50
StorEdge A5200 - 18GB Model	5-51
StorEdge A5200 18GB Model Compatibility Matrix	5-52
StorEdge A5X00 Options.....	5-53
StorEdge A5X00 Options Compatibility Matrix.....	5-54
StorEdge Media Central Notes	5-58
StorEdge Media Central	5-59
StorEdge 72” Expansion Cabinet Configuration Guide	5-61
Expansion Cabinet and Packaging Options.....	5-63
Expansion Cabinets and Packaging Options Compatibility Matrix	5-64
Tape Products	5-65
Autoloaders Ordering Flow Chart.....	5-67
Autoloaders.....	5-68

Table of Contents

L400 Ordering Flow Chart	5-70
L1000, L3500, L11000 Ordering Flow Chart	5-71
L700 Ordering Flow Chart	5-72
Tape Libraries.....	5-74
Options	6-1
Workstations Internal Expansion Options.....	6-3
Workstations Internal Expansion Options Compatibility Matrix.....	6-4
Workstations External Expansion Options.....	6-11
Workstations External Expansion Options Compatibility Matrix.....	6-12
Monitor/Graphics Accelerators Support Matrix.....	6-33
Network and Telco Servers Internal Expansion Options	6-35
Network and Telco Servers Internal Expansion Options Compatibility Matrix	6-36
Network and Telco Servers External Expansion Options	6-41
Network and Telco Servers External Expansion Options Compatibility Matrix	6-42
Workgroup Servers Internal Expansion Options.....	6-56
Workgroup Servers Internal Expansion Options Compatibility Matrix.....	6-57
Workgroup Servers External Expansion Options.....	6-64
Workgroup Servers External Expansion Options Compatibility Matrix.....	6-65
Monitor/Graphics Accelerators Support Matrix.....	6-88
Options	6-89
Enterprise Servers and Clusters Internal Expansion Options.....	6-91
Enterprise Servers and Clusters Internal Expansion Options Compatibility Matrix.....	6-92
Enterprise Servers and Clusters External Expansion Options.....	6-101
Enterprise Servers and Clusters External Expansion Options Compatibility Matrix.....	6-102
Tape Options for the Enterprise Expansion Cabinet	6-125
Tape Options for the Enterprise Expansion Cabinet Compatibility Matrix	6-126
Monitor/Graphics Accelerator Options	6-127
Monitor/Graphics Accelerator Options Compatibility Matrix	6-128
Monitor/Graphics Accelerators Support Matrix.....	6-129
SunLink TRI/S Products.....	6-132
SunLink TRI/P Products.....	6-132
SunLink HSI/S Products.....	6-133
SunLink HSI/P Products.....	6-134
Quad Fast Ethernet Card (QFE)	6-135
SunFastEthernet 10/100 SBus Adapter 2.0	6-135
Sun GigabitEthernet Adapter 2.0 (SBus and PCI)	6-136
SunFDDI SBus Adapter 6.0	6-137
SunFDDI PCI Bus Adapter	6-137
SunATM SBus Adapter 4.0.....	6-138

Table of Contents

SunATM PCI Bus Adapter 4.0.....	6-138
SunSwift SBus Adapter.....	6-139
Country Kits	6-141
Country Kits Compatibility Matrix	6-142
Localized Power Cords.....	6-146
Accessories	6-149
Software Licensing Information	7-1
APIs, Components and Frameworks	7-3
Java Dynamic Management Kit 4.1	7-5
Java Dynamic Management Kit 4.0	7-7
Java Dynamic Management Kit 3.2	7-9
Java Dynamic Management Kit 3.0	7-11
Java Dynamic Management Kit 2.0	7-13
Development Tools	7-14
Java Blend 2.0.....	7-15
Java Message Queue 1.1.....	7-16
Java Message Queue 1.0.....	7-17
Micro Focus COBOL for Solaris 2.x.....	7-18
Micro Focus COBOL Upgrades	7-19
Sun Global Application Developer Kit	7-20
Development Tools Configurations for Solaris/SPARC	7-21
Sun C and C++ Products 5.0	7-22
Sun C and C++ Products 5.0 (continued).....	7-23
Sun C and C++ Products 5.0 (continued).....	7-24
Sun C and C++ Products 5.0 Upgrades/Tradeups	7-26
FORTRAN 77 and Fortran 90 Products 5.0	7-29
FORTRAN 77 and Fortran 90 Products 5.0 Upgrades/ Tradeups.....	7-32
WorkShop TeamWare 2.1	7-34
WorkShop TeamWare 2.1 Upgrades.....	7-35
Sun Management Center 2.1.1/Developer Environment.....	7-36
Internet/Intranet Services and Clients	7-37
iPlanet Webtop 2.0 Software	7-38
iPlanet Webtop 2.0 Trade Ups.....	7-40
JavaPC 1.1	7-41
Java Web Server Software 2.0.....	7-44
Java Web Server Software 2.0 Tradeups.....	7-45
Sun Directory Services 3.1	7-46
Solstice Internet Mail Server 2.0	7-47

Table of Contents

Multimedia	7-48
ShowMe TV 1.3	7-49
Network Connectivity	7-50
SunLink CG3270 Products	7-52
SunLink Client3270 9.1.....	7-52
SunLink Peer-to-Peer and Peer-to-Peer Runtime Products.....	7-53
SunLink SNA/SNM 9.1.....	7-54
SunLink SNA3270 Gateway Products	7-54
SunLink SNA 3770/RJE 9.1.....	7-55
SunLink LU0 9.1	7-55
SunLink PPP Products.....	7-57
Solstice Frame Relay 2.0.1	7-59
Solstice FTAM 8.0.3 for Solaris 2.x and Intel.....	7-60
Solstice FTAM 8.0.3 for Solaris 2.x Upgrades	7-60
Solstice OSI 8.x for Solaris 2.x and Intel	7-61
Solstice OSI 8.x for Solaris 2.x and Intel Upgrades.....	7-62
SunLink OSI for Solaris 1.x	7-63
SunLink VT 8.0.x for Solaris 2.x	7-64
Solstice X.25 9.1.....	7-65
Solstice X.25 9.2.....	7-66
Solstice X.400 9.0 for Solaris 2.x.....	7-67
Solstice X.500 1.0 for Solaris 2.x.....	7-69
Operating Environments and Platforms	7-70
Java Embedded Server.....	7-72
Solaris Licensing Information	7-74
Solaris 8 Licensing Information	7-76
Solaris 8 Operating Environment - Media Kit Part Numbers	7-77
Solaris 8 Operating Environment - Localized Kits	7-78
Solaris 8 Operating Environment - Upgrade Licenses	7-79
Solaris Subscriptions	7-79
Solaris 7 and Solaris 2.6 Licensing Information	7-81
Upgrading to Solaris 7 and Solaris 2.6.....	7-82
Solaris 7 Part Numbers - for New Systems Only	7-83
Solaris 7 and Solaris 2.6 - Upgrade Licenses	7-84
Solaris 7 Media Kits - INTEL Platform Edition.....	7-85
Solaris 7 Upgrade Licenses	7-86
European Solaris 7 Part Numbers - for New Systems Only.....	7-87
Asian Solaris 7 Part Numbers - for New Systems Only.....	7-88
Trusted Solaris 7.....	7-89

Table of Contents

Trusted Solaris 7 Upgrades.....	7-91
Solaris 2.6 Part Numbers - for New Systems Only	7-92
Solaris 2.6 Upgrades.....	7-93
Solaris 2.6 Media Kits for INTEL Systems.....	7-94
European Solaris 2.6 Part Numbers - for New Systems Only	7-95
European Solaris 2.6 Upgrades Licenses	7-96
Asian Solaris 2.6 Part Numbers - for New Systems Only.....	7-97
Asian Solaris 2.6 Upgrade Licenses	7-98
Solaris 7 and Solaris 2.6 System Administrator Online Documentation	7-99
Solaris 7, Solaris 2.6, Solaris 2.6 HW 3/98 and Solaris 2.6 HW 5/98 Hardcopy Documentation.....	7-99
European Solaris 7 Hardcopy Documentation	7-100
European Solaris 2.6 Hardcopy Documentation	7-100
Asian Solaris 7 Hardcopy Documentation	7-101
Asian Solaris 2.6 Hardcopy Documentation	7-101
Solaris Easy Access Server 3.0.....	7-102
Solaris Easy Access Server 2.0.....	7-103
Trusted Solaris 2.5.1	7-104
Trusted Solaris 2.5.1 Upgrades.....	7-105
PC Interoperability	7-106
Solaris PC NetLink 1.1	7-107
Solaris PC NetLink 1.0.....	7-108
Solaris PC NetLink Upgrades.....	7-109
SunForum 3.0	7-110
Security	7-111
SunScreen Secure Net 3.1	7-112
SunScreen Secure Net 3.1 Upgrades	7-113
iPlanet Secure Net 3.0 Localized Versions	7-114
iPlanet Secure Net 3.0 Localized Versions Upgrades	7-116
SunScreen SKIP 1.5.1	7-117
SunScreen SKIP 3.0.7 for Windows 95/Windows NT.....	7-118
Server Performance Software	7-119
Sun Cluster 2.2 Configuration Information.....	7-120
Sun Cluster 2.2 Order Approval Process.....	7-121
Sun Cluster 2.2	7-124
Sun HPC ClusterTools	7-127
Storage Software	7-128
Sun StorEdge Instant Image	7-129
Sun StorEdge Instant Image Localized	7-130
Sun StorEdge Network Data Replicator 2.0.....	7-131

Table of Contents

Solstice Backup 5.5.1 Notes	7-132
Solstice Backup 5.5.1 Ordering Flow Chart.....	7-133
Solstice Backup 5.5.1 Sample Configurations	7-135
Solstice Backup 5.5.1	7-136
Solstice Backup 5.1 for Solaris 2.x.....	7-139
Solstice Backup 5.5.1 Upgrades	7-140
Solstice DiskSuite Products.....	7-141
Solstice DiskSuite Upgrades	7-142
Sun StorEdge LibMON 2.0	7-143
Sun StorEdge LibMON 2.0 Upgrades.....	7-145
VERITAS Volume Manager 3.0.4 Ordering Notes	7-146
VERITAS Volume Manager 3.0.4	7-147
VERITAS Volume Manager Upgrades.....	7-148
VERITAS File System 3.3.3	7-149
VERITAS File System 3.3.3 Upgrades.....	7-150
VERITAS Volume Manager and VERITAS File System OEM License	7-151
VERITAS Volume Manager 3.0.4 and VERITAS File System 3.3.3 License Tier Definitions	7-152
VERITAS NetBackup 3.2/Storage Migrator 3.2.....	7-153
VERITAS NetBackup Software Ordering Flowchart	7-154
VERITAS NetBackup Sample Ordering Flowchart.....	7-156
VERITAS Storage Migrator Ordering Flowchart	7-157
VERITAS Data Global Manager Ordering Flowchart.....	7-158
VERITAS Site License.....	7-164
System and Network Management	7-165
Sun Trunking 1.2.1 Software.....	7-167
Solstice CMIP 8.2.1.....	7-169
Solstice CMIP 8.2.1 Upgrades	7-170
Solstice Enterprise Manager 3.0.....	7-171
Solstice Enterprise Manager 2.1	7-176
Solstice Enterprise Manager 2.1 Upgrades.....	7-179
Solstice GDMO Builder 1.0	7-180
Solstice TMN Agent Tester 1.1.....	7-181
Solstice TMN Agent Tester 1.1 Upgrades.....	7-181
Solstice TMN Agent Toolkit 2.0	7-182
Solstice TMN Agent Toolkit 2.0 Upgrades.....	7-183
Solstice TMN Product Set CD	7-184
Solstice TMN/SNMP Q-Adapter 1.0.....	7-185
Solstice TMN Script 1.1	7-186
Solstice TMN Script 1.1 Upgrades.....	7-187

Table of Contents

Solstice Site Manager and Domain Manager 2.3 for Solaris 2.x, 1.x, and Intel	7-188
Solstice Site Manager and Domain Manager 2.3 for Solaris 2.x, 1.x and Intel Upgrades	7-189
Solaris Resource Manager 1.2/Solaris Bandwidth Manager 1.6	7-191
Solaris Resource Manager 1.2/Solaris Bandwidth Manager 1.6 (continued).....	7-192
Solstice AutoClient 2.1 for Solaris 2.x	7-193
Sun Management Center 2.1.1	7-194
Sun StorEdge Management Console 1.0 / Sun StorEdge Component Manager 1.0	7-195
Hardware Upgrades	8-1
SunUpgrades Product Overview	8-2
Sun Ray Enterprise Server Upgrades	8-5
Sun Ultra 5 Upgrade Configurations	8-7
Upgrades to Sun Ultra 5	8-8
Sun Ultra 10 Upgrade Configurations	8-14
Upgrades to Sun Ultra 10	8-15
Upgrades to Sun Ultra 60	8-23
Upgrades to Sun Ultra 80	8-29
Upgrades to Sun Ultra 80	8-30
Sun Netra t 1120/ 1125 ATO Upgrade Ordering Flow Chart	8-38
Upgrades to Netra t 1120 and Netra t 1125	8-39
Upgrades to Netra t 1400	8-41
Upgrades to Netra t 1405	8-42
Upgrades to Netra t 1400 and Netra t 1405 Modules	8-43
Upgrades to Netra t1 Model 105	8-44
Upgrades to Netra t1 Model 100	8-46
Upgrades to Netra st D130	8-47
Sun Netra ft 1800 Upgrades Ordering Flow Chart	8-48
Sun Netra ft 1800 Telco Server Upgrades	8-49
Upgrades to Ultra Enterprise 2 Servers - Modules	8-51
Upgrades to Sun Enterprise Ultra 5S Servers	8-53
Upgrades to Sun Enterprise Ultra 10S Servers	8-54
Ordering Flow Chart for Upgrades to Enterprise 250	8-55
Sun Enterprise 250 Upgrade Product Ordering Notes	8-57
Upgrades to Ultra Enterprise 250 Servers	8-58
Ordering Flow Chart for Upgrades to Enterprise 450	8-62
Sun Enterprise 450 Upgrade Product Ordering Notes	8-64
Upgrades to Ultra Enterprise 450 Servers	8-65
Ordering Flow Chart for Upgrades to Enterprise 220R	8-69
Upgrades to Ultra Enterprise 220R Servers	8-71
Ordering Flow Chart for Upgrades to Enterprise 420R	8-75

Table of Contents

Upgrades to Ultra Enterprise 420R Servers	8-77
Enterprise 3500-4500 CTO CPU/Memory Board Upgrade Flowchart	8-82
Enterprise 3500-4500 Configure-to-Order CPU/Memory Board Upgrade	8-83
Enterprise 3500-4500 CTO CPU/Memory Board Consolidation Upgrade Flowchart	8-84
Enterprise 3500-4500 Configure-to-Order CPU/Memory Board Consolidation Upgrade	8-85
Ordering Flow Chart for Intra Enterprise Server Upgrades	8-86
Ordering Flow Chart for Upgrades to Enterprise 3500	8-87
Upgrades to Enterprise 3500	8-88
Upgrades to Enterprise 4500	8-96
Enterprise 5500-6500 CTO CPU/Memory Board Upgrade Flowchart	8-105
Enterprise 5500-6500 Configure-to-Order CPU/Memory Board Upgrade	8-106
Enterprise 5500-6500 CTO CPU/Memory Board Consolidation Upgrade Flowchart	8-107
Enterprise 5500-6500 Configure-to-Order CPU/Memory Board Consolidation Upgrade	8-108
Ordering Flow Chart for Intra Enterprise Server Upgrades	8-109
Ordering Flow Chart for Upgrades to Enterprise 5500/6500	8-110
Upgrades to Enterprise 5500	8-111
Upgrades to Enterprise 6500	8-122
Hardware Upgrades	8-130
Ordering Flow Chart for Upgrades to Enterprise 10000	8-132
Upgrades to Enterprise 10000	8-135
Enterprise 10000 Board Upgrades	8-138
Enterprise 10000 CTO Board Upgrades Flow Chart	8-139
Enterprise 10000 Configure to Order Board Upgrades	8-140
Enterprise 10000 Capacity-On-Demand Upgrades Ordering Flow Chart	8-141
Enterprise 10000 Capacity-On-Demand System Upgrade Configuration Guidelines	8-142
Enterprise 10000 Capacity-On-Demand Upgrade Sample Configurations	8-143
Enterprise 10000 Capacity-On-Demand Upgrades	8-144
Server Consolidation Trade-In Program Notes	8-146
Server Consolidation Trade-In Program	8-148
Ordering Flow Chart for Upgrades to E10000 Capacity-On- Demand Server Consolidation	8-162
E10000 Capacity-On-Demand Server Consolidation	8-163
Enterprise 10000 Server Consolidation Capacity-On-Demand CTO Upgrade Flow Chart	8-165
Enterprise 10000 Server Consolidation Capacity-On-Demand CTO Upgrade Guidelines	8-166
StorEdge A1000 Upgrades	8-168
StorEdge D1000 Upgrades	8-170
A1000/D1000 Disk Upgrades	8-172
StorEdge A3500 Upgrades	8-173
StorEdge A5100 Upgrades	8-181
StorEdge A5200 Upgrades	8-183

Table of Contents

Module Upgrades	8-190
Memory Module Upgrades.....	8-195
Enterprise System Board Upgrades.....	8-197
Miscellaneous Board Upgrades	8-200
Monitor Upgrades.....	8-202
Graphics Upgrades	8-203
Disk Upgrades	8-205
Tape Drive and Library Upgrades	8-207